GOLDEN SELECT GROUTED RIGID CORE ENGINEERED SPC VINYL TILE

This document provides the installation instructions for Golden Select Grouted Rigid Core Luxury Vinyl Tile.

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

IMPORTANT NOTE: The owner/purchaser must inspect for color, finish and the quality before installation. The manufacturer cannot be held responsible for costs incurred when a floor with visible defects has been installed.

IMPORTANT WARNING: Your **existing** resilient flooring, backing, lining felt, asphalt cut-back adhesives or other adhesives **MAY** contain asbestos fibers and/or crystalline silica. DO NOT grind, chip, sand, drill, saw, bead-blast or pulverize this material in any way; either by hand or by machine. Avoid creating dust when working in contact with these materials. The inhalation of dust from these materials is a known cancer and respiratory tract hazard. Unless you are absolutely certain that the resilient flooring you are removing is a non-asbestos material, you must assume that it contains asbestos. Local regulations may require that the material be tested by an approved laboratory or agency for asbestos content and, if confirmed, regulated removal / disposal of the material may be required.

For more information, refer to current edition of the Resilient Floor Covering Institute (RFCI) publication: "Recommended Work Practices for Removal of Resilient Floor Coverings" (www.rfci.com)

GENERAL GUIDELINES

All instructions and recommendations are based on the most recent information available. They should be followed for an ideal installation.

- Rigid core luxury vinyl tiles should be installed in indoor climate-controlled locations between 18° 29°C (65° 85°F). Rigid core luxury vinyl should NEVER be installed in an outdoor/ exterior setting or in any type of garage.
- Rigid core luxury vinyl tiles should be acclimated in the climate-controlled locations for 48 hours before starting installation.
- Rigid core luxury vinyl tiles should only be installed after the jobsite has been cleaned and cleared of debris that could potentially damage a finished installation.
- During the installation, mix and install panels from several different cartons to minimize shade variation.
- The finished installation should be protected from exposure to continuous sunlight.
- Rigid core luxury vinyl tiles cannot be installed with adhesives. The use of any sort of adhesive during the installation will void the warranty.
- Rigid core luxury vinyl tiles cannot be installed in an unheated environment such as a cottage, RV or solarium.

SUBFLOOR INFORMATION

Although rigid core luxury vinyl tiles are designed to be a "floating" floor installation, proper preparation of the subfloor is still a major part of a successful installation. Roughness or unevenness of the subfloor may show through the new floor, resulting in an unsightly surface and cause excessive wear on high spots or indentation on low spots. All subfloors must be level flat to 4.7 mm (3/16 in) per 3.3 m (10 ft). All subfloor and underlayment patching must be done with a non-shrinking, waterresistant Portland cement patching compound.

A. Concrete Subfloors

- Concrete subfloors must be dry, smooth and free from dust, solvent, grease, oil, asphalt sealing compounds and other extraneous materials. The surface must be hard and dense, and free from powder or flaking.
- New concrete slabs must be thoroughly dry (at least 60 days) and completely cured. The final responsibility for determining if the concrete is dry enough for installation of the flooring lies with the floor covering installer.
- Holes, grooves, expansion joints and other depressions must be filled with a latex underlayment, and troweled smooth and feathered even with the surrounding
- Concrete subfloors must have a minimum of 6-mil poly film between the concrete and the ground.

B. Wood Subfloors

- Wood subfloors must be suspended at least 455 mm (18 in) above the ground. Adequate cross-ventilation must be provided, and the ground surface of a crawl space must be covered with a suitable vapor barrier.
- Wood subfloors directly on concrete or installed over sleeper construction are NOT suitable for the installation.
- All wood and wood composition panels, including plywood, OSB, flake board and particle boards, can be used providing they are smooth, flat, structurally sound and free of deflection.
- A 6 mm (1/4 in) underlayment panel should be installed over the subfloor if the surface of the wood subfloor is not smooth.
- Wood subfloors must be dry and well secured.

C. Existing Floor Coverings

- Rigid core luxury vinyl tiles can be installed over most existing hard-surface floor coverings provided the existing floor surface is smooth, or can be made smooth.
- Ceramic tiles should be made smooth by applying a cementious overlay such as patching or leveling compound manufactured specifically to smooth out ceramic
- For existing resilient floor, it may be required to apply a skim coat of embossing leveler over a deeply embossed floor. Heavily cushioned vinyl floor or vinyl floor consisting of multiple layers are NOT suitable subfloor for installation.

D. Indoor Radiant Heat and Underfloor Heating

- Use only recommended flooring adhesive over manufacturer's recommended plywood substrate.
- Turn the heat off for 24 hours before, during and 24 hours after installation when installing over radiant heated subfloors
- Failure to turn the heat off may result in shortened working time of the adhesive.
- Floor temperature must not exceed 29°C (85°F).
- Can be installed over electric, water and every other type of underfloor heating.
- · Failure to strictly follow adhesive manufacturer's guidelines may result in failure and void warranty.

WARNING: HEATING MATS ARE NOT RECOMMENDED FOR USE WITH RIGID CORE LUXURY VINYL FLOORING. IT IS BEST TO INSTALL THE RIGID CORE LUXURY VINYL FLOOR OVER EMBEDDED FLOOR HEATING SYSTEMS.

TOOLS AND SUPPLIES REQUIRED

Crosscut power saw, chalk line/string, pencil, tape measure, tapping block, rubber mallet, pull bar, painter's tape, safety glasses.

INSTALLATION

TILE LAYOUT

Do not secure individual click engineered vinyl tiles to the subfloor as they are designed to be a floating floor. All doorjambs should be undercut and cabinets cannot be installed on top of the click engineered vinyl tiles. Wall moldings and transition strips should be installed over any exposed tile edges but should not be fastened through the tile.

- First, determine how you want the flooring to run. Typically for tile products, the flooring runs the length of the room. There may be exceptions since it is all a
- To avoid narrow tile widths or short tile lengths near the walls/doors, it is important to do some pre-planning. Using the width of the room, calculate how many full boards will fit into the area and how much space remains that will need to be covered by partial tiles. Divide the remaining space by two to calculate the width of the partial tiles. Do the same along the length.
- Note that if the first row of tiles does not need to be trimmed in width, it will be necessary to cut off the unsupported tongue so that a clean, solid edge is toward
- Starting at a corner going from left to right (place the tongue side against the wall) use the tapping-block to lock the short ends together. Create an expansion space of 3/8" (10mm) between the wall and flooring of the first row. Use spacers to maintain expansion gaps.
 - Note: While installing your flooring, we recommend maintaining uniform "expansion gaps" around the perimeter of the floor or at any vertical obstruction. It is also recommended placing a transition molding when required thus allowing for transitional expansion preserves the structural integrity of the floating
- Start each new row with the leftover pieces from the previous row. 6.
- Please take particular care to ensure the first three rows are perfectly straight. Lock tiles with the aid of tapping-block to insure tiles are properly secured. Note: Never use hammer on tiles as it will damage flooring. 8.
- Repeat all steps until rows are completed.

INSTALLING UNDER A DOOR JAMB:

- 1. Installation under moldings (such as door jambs) may require that the top lip of the groove on the end be reduced in size. 2. Using a small plane or utility knife, carefully shave off the ledge of the groove (Figure 1).
- 3. After the groove ledge has been trimmed, put the board in place and tighten with a pull bar to test for a tight
- fit. The installer must be sure that the required expansion gap has been maintained and the flooring is not 4. If the fit is incorrect, re-trim until the fit is correct.



5. Place a bead of wood glue on the bottom lip of the groove.

6. Insert the tongue into the grove and tighten the fit with a pull bar. Hold the tile in place with painter's tape until the glue is dry. Do not use masking tape or duct tape as they may damage the floors finish.

AFTER INSTALLATION

- Flooring should be one of the last items installed in a project. In order to protect the floors while other projects are being completed, use rosin paper and painter's tape to hold the rosin paper to the floor (other tapes may damage the finish). Clean the floor thoroughly before laying the rosin paper to ensure that no debris is
- trapped underneath. DO NOT USE plastic film or other non-breathing coverings as this can cause the floor to become damaged from excess humidity. Dust mop or vacuum your floor to remove any dirt or debris.
- It is suggested that you buff the floor with lamb-wool pads in order to remove any loose splinters, residues, foot prints, etc. Install any transition pieces that may be needed (reducers, T-moldings, nosing, etc.).

PROTECTION AND MAINTENANCE Lasting beauty can be achieved through purchasing a quality floor covering and on-going maintenance.

- Furniture should be moved onto the newly installed floor using an appliance hand truck over hardboard runways.
- Avoid extended exposure to direct sunlight. It is recommended to close the blinds or drapes during peak sunlight hours. Floor coverings exposed to excessive heat and light are subject to thermal degradation. Use the appropriate precautions to minimize potential effects on the floor covering.
- Oil or petroleum-based products can result in surface staining. Do not track asphalt-driveway sealer or automobile-oil drips onto the vinyl floor covering.

- Frequently moved furniture should be equipped with felt pads to avoid scratching the floor. Heavy furniture and appliances should be equipped with non-staining large surface floor protectors. Furniture with castors or wheels must be easy swiveling, large surface non-staining and suitable for resilient floors. Do NOT use ball type castors as they can damage the floor.
- Use walk off mats at entrances to prevent dirt and grit from being tracked on to the floor.
- Sweep or vacuum the floor regularly to remove loose dirt. Do NOT use vacuums that use a beater bar or turn beater bar off.
- Do NOT use electric brooms with hard plastic bottoms with no padding.
- Clean up spills immediately.
- Damp mop as needed using clean water and a diluted floor cleaner. Do NOT use harsh cleansers, chemicals, abrasive scrubbing tools, detergents, abrasive cleaners, or "mop and shine" products.
- Vinyl flooring, like other types of smooth floors, may become slippery when wet. Allow time for floor to dry after washing. Immediately wipe up wet areas from spills, foreign substances or wet feet.

REPAIRS

In the unlikely event that a rigid core luxury vinyl tile is damaged for whatever reason, the simplest method is to disconnect the tiles carefully (protecting the tongue and groove edges) until the damaged tile can be removed. Then replace the damaged tile with a new one and reassemble the disconnected tiles. This typically works for tiles that are close to the two long perimeters of a room.

For damaged tiles that are not close to the perimeter, you may have to remove the damaged tiles and insert new pieces without the short and long end grooves.

- 1. Using a sharp utility knife and a straight edge, cut out the center of the damaged tile by leaving approximately 2.5 cm (1 in) strip attached to the adjacent tiles.
- 2. Carefully cut back from the four corners of the tile to the inside edges in space left by the cut out tile.
- 3. Remove the tile edges carefully from the adjacent tiles making sure the tongues and grooves of the adjacent tiles are not damaged.
- 4. Using a utility knife, remove the tongue strip on both the long and short ends of the replacement tile. In addition, remove the groove strip of the short end of the replacement tile.
- 5. Place some doubled sided carpet tape along the three sides of the adjacent tiles where the tongues and the groove of the replacement tile have been removed. Only the top side release paper of the carpet tape should be removed. The bottom side release paper should NOT be taped on top of the subfloor.
- 6. Position the replacement tile by engaging the groove of the long side into the tongue of the adjoining tile and pushing down on the other three sides. The carpet tape will hold the replacement tile in place with its adjacent tiles. Use a hand roller to further secure the tape.

WARRANTY

Golden Select Rigid core luxury Vinyl tiles are covered by a limited warranty of 35 years for residential use and a limited warranty of 15 years for light commercial use. The stipulations of the limited residential warranty are as follows:

- The flooring will be free of manufacturing defects.
- The flooring surface will not wear through under normal household use.

The following conditions apply to the warranty and may void the warranty if not followed correctly:

- The flooring must be installed according to the instructions provided.
- If filing a warranty claim, it must be submitted within 30 days of the discovery of the damage.
- Any damage to the wear layer must be evident and visible, measuring at least 13 cm² (2 square inches).
- Proof of purchase, such as a bill of sale is mandatory when requesting warranty service.
- The warranty is non-transferable.
- The manufacturer reserves the right to designate a representative to inspect the floor in question and remove samples for analysis.
- The warranty includes the replacement material, and excludes labor costs.

WARRANTY EXCLUSIONS

- Damage due to improper installation, care, cleaning, or maintenance.
- Use of any adhesive or solvent material during installation.
- Installation of rigid core luxury vinyl in an outdoor/exterior setting or in any type of garage.
- · Damage caused by severe impact, scratching, or cutting, fire, water damage, alterations, or any other wear or damage caused by acts of God.
- The use of rigid core luxury Vinyl tiles in an unheated environment such as a cottage, RV or solarium.
- Flooring dulled by soaps, detergents, harsh chemicals, dressings, one-step cleaners or wax.
- Damage caused by high heels, burns, cigarette burns, cuts, scratches, gouges, and indentations including damage from improper floor protectors and furniture rests; staining caused by dyes tracked from carpet, fertilizers, coal, tar, driveway sealers, oil drippings or other similar materials.
- Problems due to moisture and/or alkalinity of the subfloor.
- Flooring installed over unstable subfloors (particleboard, chip wood, or pressboard) or improperly prepared subfloors, and or wet/cold floor are not covered by the limited warranty.
- Discoloration from mold or from flooding, leaking plumbing or appliances, water entering through sliding glass doors or similar conditions.
- Discoloration by exposure to direct sunlight or heat generation.
- Discoloration caused by the use of area rugs or floor mats. Use non-staining mats, for rubber mats will discolor the floor.

For assistance with assembly or installation, please contact our Technical Support Department by email at techsupport@goldenselect.ca or by telephone at 1-800-267-3183. For customer service, please contact our customer service department at info@goldenselect.ca. For questions regarding the warranty, please contact our Customer Service Department at warranty@goldenselect.ca. Visit our website at www.goldenselect.ca.